
CLASSE 924/925

Portable Radiation
Survey Meter Training
(Classroom/Online)



Why?

- ✧ Verify integrity of new or altered shielding
- ✧ Verify work/public areas comply w/ALARA levels
 - *Below 0.05 mrem/h outside exclusion areas averaged over 1yr*
 - *Below 2 mrem/h averaged over 1 hour*
- ✧ Check activated materials (see CLASSE 121 for policy)
 - *It takes a lot of electron radiation >6 MeV to activate!*
 - *High Z materials more susceptible (e.g. some welds)*
 - *Typically in Linac (e⁺ converter & elsewhere), injection lines, collimators*
 - *Below 0.05 mrem/h on contact is “not activated”*
 - *“Weakly activated”*
 - 0.05-50 mrem/h on contact, AND
 - < 0.05 mrem/h at 60 cm
 - *“Highly activated” is*
 - >50 mrem/h on contact, OR
 - >0.05 mrem/h at 60 cm
- ✧ Check radioactive sources (rare)

Technology

- ✧ Usually looking for gammas (photons, γ 's)
 - Some radioactive sources emit betas (electrons)
 - On rare occasions one looks for neutrons
- ✧ Geiger-Mueller tube (beta, gamma)
 - Anode at high voltage surrounded by gas
 - Photon knocks off an atomic orbital electron (photo-electric effect) in the tube wall or gas
 - Gas is ionized, avalanche electrons collected at anode
 - Current is roughly proportional to **rate** of radiation
 - Some probes/meters are “energy compensated” meaning dose rate accounts for energy spectrum
- ✧ Neutron detection requires a different probe

Gamma energy loss

Photo-electric effect dominates!

Log scale

G-M tube
operational
range




Figure 33.15: Photon total cross sections as a function of energy in carbon and lead, showing the contributions of different processes [51]:

$\sigma_{\text{p.e.}}$ = Atomic photoelectric effect (electron ejection, photon absorption)

σ_{Rayleigh} = Rayleigh (coherent) scattering—atom neither ionized nor excited

σ_{Compton} = Incoherent scattering (Compton scattering off an electron)

κ_{nuc} = Pair production, nuclear field

κ_e = Pair production, electron field

$\sigma_{\text{g.d.r.}}$ = Photonuclear interactions, most notably the Giant Dipole Resonance [52].

In these interactions, the target nucleus is broken up.


Original figures through the courtesy of John H. Hubbell (NIST).



Geiger-Mueller tube

Interaction of gamma radiation with G-M tube wall


Anode wire




Key

- Ionisation event
- Ionising electron path
- Liberated electron path
- ★ Interaction with tube wall

Detection of higher energy gamma in a thick-walled tube. Secondary electrons generated in the wall can reach the fill gas to produce avalanches. Multiple avalanches omitted for clarity



Pancake probe



Circular anode/cathodes

GSM-115



Other meters





CPM & mR/h reversed!



Microrem

More meters




Probe selection

- ✧ “Pancake probe” has thin window
 - *Most sensitive probe for low energy betas & gammas*
 - **Absolute calibration of dose rate is NOT reliable**
 - *Most useful for **locating** low energy radiation sources, NOT measuring absolute ALARA levels*
 - *Beta > 100 keV*
 - *Gamma: 20 keV – 2 MeV*
- ✧ Energy Compensated probe
 - *Low energy photons get too much weight relative to their impact on dose in a GM tube*
 - Compensation usually done by filtering out some fraction of them
 - *Best for ALARA measurements*
 - *Gamma 50 keV to 2 MeV*
- ✧ Neutron probe
 - *Only for neutrons; response can be slow*



Energy Compensation

Geiger-Muller tube energy compensation




Probes for portable meters

Gamma –
energy compensated



Battery & Range



- Use mR/h (top scale)
- This one is 0.2 mR/h max
- 200 mR/h max on X1000
- ~9V/900V



Response time; sound

- ☐ Frequently response time is adjustable
- ☐ Fast response can result in jumpy readings
- ☐ Slow response can require much patience!



GM tube saturation

- ✧ At high dose rates a GM tube can “saturate”
- ✧ This means that too many gas atoms have reached excited states, causing a long dead time for the meter as the avalanche clears
- ✧ First, the reading may very rapidly go high or off-scale
- ✧ Next, during such dead time, the meter may remain pegged at zero, the exact opposite of what it should
- ✧ Hence, it is generally recommended to either
 - *Start on the least sensitive ($\times 1000$) scale and work down from there, gradually; or*
 - *Bring the probe from a low radiation area to the target location slowly, while watching response and not letting it go off-scale*



Measuring background level

- ✧ Background in Wilson Lab typically ranges from 10-40 micro-rem/h (0.01-0.04 mrem/h)
- ✧ Depends upon
 - *Overburden (concrete and soil above you that shield cosmic rays)*
 - *Proximity to weakly active materials (like concrete)*
- ✧ Generally, we ignore background when surveying activated material and write the full, unsubtracted value on the tag
 - *You may indicate bgd level on the tag, clearly, if you like*
- ✧ When surveying for effectiveness of shielding, background is often measured and recorded, because compliance with the 50 micro-rem/h threshold may require it, so record both background level and full, unsubtracted value measured at a given location



Operation

- ✧ Look for any DO NOT USE labels or markings
- ✧ Inspection/calibration should be no more than 6 months overdue
 - *Could be technically expired. Generally annual, but delays can occur*
- ✧ Do a battery check (usually 9V)
 - *Do not use if weak! Get another meter or change batteries.*
- ✧ If there is a “check source” mounted on the meter, verify that the probe responds to it
- ✧ Check background level away from source
 - *May have to wait for stable operation*
- ✧ Start on biggest scale (least sensitive)
 - *Otherwise can saturate and become unresponsive, faking 0 dose rate*
 - *Alternately, bring in probe from a distance very slowly to target, always keeping the reading on-scale*
- ✧ Adjust response time; wait for stable response
- ✧ If a reading seems odd, double check with a 2nd meter
- ✧ **Power off unit!**



Notes

- ✧ If any meter or probe behaves questionably
 - *Tag it with the date, your name, and DO NOT USE*
 - *Bring to Radiation Safety Specialist*
- ✧ If you ever have a question, contact
 - *Radiation Safety Specialist*
 - *Safety Director*
 - *Permit Holder*
 - *CHESS Safety Officer*
 - *CESR Technical Director*



